

Notes on connection and control of FORWARD vision CCTV  
Keyboard type 500

**Kb\_Forw1.bin**

Settings (fixed):  
9600 baud, off parity, 1 stop bit, 8 data bits

Important note:

The "SET SIMPLEX MODE" telemetry mode must be set on the keyboard.  
This can be set using keyboard setup code "94". For further information on this refer to the manufacturer's manual (point 9.4).  
The dome is connected via RS485 and was turned contrary to the description in the manual when we conducted our test.  
Therefore the TxD A output must be to RxD – (B) on the DNI and correspondingly TxD B to RxD + (A).

Forward keyboard dome and DNI connection:

