

Notes on connection and control of JVC dome
TK-C676 U/E series

C_JVC6_1.bin

Settings (fixed):
9600 baud, even parity, 1 stop bit, 8 data bits

Important:

Before the JVC dome is started up, it has to be set to *Multidrop* communication mode (DIP switch 4:ON) and *Simplex* (DIP switch 5:ON) (please check the quoted DIP positions against your specific manual!). .

Please ensure proper setting of the RS485 address at the dome (settings of the round DIP switches 1+2)!

Connection of JVC dome and DNI-422

