

Notes on connection and control of VCL dome with
'VCL TP Protocol'

C_VCL_1.bin

Settings (default)
9600 baud, none parity, 1 stop bit, 8 data bits

The receiver address (1-128) must be set at the DIP switches of the DOME (please refer to the manual for details of the settings).

Connection of VCL dome and DNI-422

