

## Notes on connection and control of Vista Power dome

### **C\_Vista1.bin**

Settings (default)

19,200 baud, none parity, 1 stop bit, 8 data bits

Please ensure correct setting of the receiver address at the DIP switches of the dome (refer to the respective manual for setting information)!

### Connection of Vista dome and DNI-422

