

Notes on connection and control of Ultrak dome KD6/KD6-Z
'MaxPro' protocol

C_Ultra1.bin

Settings (fixed):
9600 baud, even parity, 1 stop bit, 8 data bits

Important:

The KD6 dome must be set to "MaxPro" mode prior to startup:
DIP switch 4 (please refer to the respective manual for the DIP setting).

Please ensure proper setting of the RS-485 address at the dome (settings of DIP switches 1 - 3)!

Connection of Ultrak dome KD6 and DNI-422

