

## Notes on connection and control of BBV keyboard Tx1000KB:

### **KB\_BBV\_1.bin**

Settings (fixed):  
9600 baud, none parity, 1 stop bit, 8 data bits

### Connection of BBV keyboard and DNI-232

