

Notes on connection and control of American Dynamics dome  
(RS422 communication protocol)

**C\_AD422.bin**

Settings (fixed):  
4800 baud, no parity, 1 stop bit, 8 data bits

**Important:**

The dome is operated exclusively in so-called “RS422 mode”. This must not be confused with “Manchester Data” or “SensorNet”.  
The management of the default settings comprises up to 96 items and takes effect with series AD DeltaDome, SpeedDome Optima and SpeedDome Ultra V (from version 3.06).

The dome is generally connected using a 9-pin screw terminal. The assignment is shown in the manual under the heading “RS422 data and power”.  
The **Data Out** – High or Low outputs are left unswitched.

AD dome and DNI connection:

