

Notes on connection and control of FORWARD dome
from series Mic1-300

C_Forw1.bin

Settings (fixed):
9600 baud, off parity, 1 stop bit, 8 data bits

Important:

The dome is connected via RS485 and was turned contrary to the description in the manual when we conducted our test.

Therefore the RxD A input must be to TxD – (B) on the DNI and correspondingly RxD B to TxD + (A).

Forward dome and DNI connection:

