

Notes on connection and control of Ernitec keyboard Typ 150xM
('ERNA' protocol)

Kb_Ern_1.bin

Settings (fixed):
2400 baud, none parity, 1 stop bit, 8 data bits

Important note:

Keyboard type "Direct Camera Control" must be set on the keyboard.
This usually occurs by way of the keyboard setup (please refer to the manufacturer's manual).
The keyboard is connected via a SUB-D plug. In addition to the optional RS-232, the required RS-485 transmission lines Tx+ (pin 6) and Tx- (pin 7) are lead through here.

Connection of Ernitec keyboard and DNI-422

