

Notes on connection and control of Mark Mercer keyboard  
(Meridian Control Protocol)

**Kb\_MMer1.bin**

Settings (fixed):

9600 baud, none parity, 1 stop bit, 8 data bits

Control note:

Please first enter a valid camera number (= dome address, e.g. "1" + "Cam" for address 1) following voltage supply. Then proceed as described in the Mark Mercer manual.

Connection of Mark Mercer keyboard and DNI-422

